
WEST OCEAN ASSOCIATION

Window Covering Installation Requirements

Installation Requirements:

- ❖ All window covering treatments must be installed directly into the concrete. The drilling into the concrete should be limited to accommodate fasteners no longer than ¾” in length. For those products that have cord tensions, the cord tensions brackets will be glued to the aluminum frame using a clear adhesive. Window covering treatments can not be installed into the window’s aluminum frame.

West Ocean Association would like to suggest the following window covering styles:

- ❖ Shades
 - Silhouette Shades
 - Luminette
 - Skylines Window Panels
 - Vertical Blinds
 - Designer Screen Shades
 - Roller Shades